

Customer Name	Ludvig Svensson		
Customer Address	Bangatan 8 I 511 82 Kinna I Sweden		
Contact	Caroline Hultberg		
Test Requested	Determination of antibacterial according to ISO 20743:2021 (Abso	-	-
			Number Received
Sample Description	Trevira CS treated with NordShield BioLayr	Treated	1
	Untreated control	Non-treated	1
Date of Receipt	21 June 2023		
ASC Code	ASC004407		
Commencement Date	05 July 2023		
Report Number	C568		
Report Date	07 July 2023		



1. Purpose

To determine, as per the standard ISO 20743:2021 [1], the antibacterial activity of a textile product against *Klebsiella pneumoniae* after 24 h incubation.

2. Sample Description

	Table 2.1. Description of samples			
	Test (treated) specimens	Control (non-treated) fabric		
Туре	Trevira CS treated with NordShield BioLayr	Untreated control		
	Supplied by Ludvig Svensson	Supplied by Ludvig Svensson		
Weight	0.4 g ± 0.05g	0.4 g ± 0.05g		
Shape	Square	Square		



3. Procedure

The procedure was performed according to ISO 20743:2021 [1] and under the conditions summarised in Table 3.1.

Table 3.1. Test set-up details			
ISO 20743 methods used	Inoculation method	absorption method (test bacterial suspension inoculated directly onto specimens)	
	Quantitative measurement method	colony plate count method	
Test bacteria suspension	Name of test bacteria	Klebsiella pneumoniae	
	Strain number	ATCC 4352	
	Quantity inoculated	0.2 ml	
	Concentration of inoculum	2.45 x 10⁵ CFU/ml	
Incubation time		24 h	
Volume of sample plated		1 ml	





4. Results

4.1. Antibacterial activity (A) calculation

The logarithmic values of the number of viable bacteria (colony forming units per millilitre) recovered from the specimens immediately after inoculation and after 24 hours of incubation are summarised in Table 4.1. All calculations were performed according to the formulae in ISO 20743:2021 [1].

Table 4.1. Summary of Results for 24 h K. pneumoniae				
Sample			Log ₁₀ values	
	n logarithm of arithmetic average of the f bacteria obtained from three control specimens after incubation	lg C _t	9.3	
numbers o	n logarithm of arithmetic average of the f bacteria obtained from three control nens immediately after inoculation	lg C ₀	5.7	
numbers of b	The common logarithm of arithmetic average of the mbers of bacteria obtained from three antibacterial $Ig T_t$ test specimens after incubation		2.3	
the common logarithm of arithmetic average of the numbers of bacteria obtained from three antibacterial test specimens immediately after inoculation		lg T _o	3.1	
F	the growth value on the control fabric ($\lg C_t - \lg C_0$)	=	3.6	
G	the growth value on the test fabric $(IgT_t - IgT_0)$	=	-0.8	

Α	the antibacterial activity value (F-G)	=	4.4

The **antibacterial activity** (A) refers to the activity of an antibacterial finish used to prevent or mitigate the growth of bacteria, to reduce the number of bacteria, or to kill bacteria. It is calculated as the difference, after inoculation and incubation, in the log number of viable bacteria recovered from the antibacterial-treated product versus the number recovered from the untreated control fabric.

According to ISO 20743:2021 [1], the efficacy of antibacterial property of the test fabric can be considered as shown in Table 4.2.

Table 4.2 Efficacy of antibacterial property			
Efficacy of antibacterial property	Antibacterial activity A		
Significant	≥2 to <3		
Strong	≥3		

airmid healthgroup Itd 2056 Castle Drive, Citywest Business Campus, Dublin 24, D24 YH58, Ireland T: +353 1 6336820 E: info@airmidhealthgroup.com W: airmidhealthgroup.com Directors: Dr Bruce Mitchell [Chairman and CEO], Dr John McKeon, Robert Jenkins, Hubert Lippe, Rainer Roten Co Reg. No.: 444684 VAT Registration: IE9669332M V1FM533 Page 4 of 6



4.2. Judgement of test effectiveness

When the conditions specified in ISO 20743:2021 [1] and summarised in Table 4.3 are satisfied, the test is judged to be effective. When the test is judged to be ineffective, a retest shall be carried out.

Table 4.3. Judgement of ISO 20743 test effectiveness					
Condition	Requirement		Requirement Result		Criteria Met
Test inoculum concentration	1E+05 1	to 3E	+05	2.45E+05	Yes
The difference (in common logarithm) in extremes of the number of bacteria for the three <i>control specimens</i> immediately after inoculation and after incubation	<	<1		0.10 and 0.09	Yes
The growth value obtained in the plate count method	2	≥1		3.59	Yes
The difference (in common logarithm) in extremes of the number of bacteria for the three <i>test specimens</i> immediately after inoculation and after incubation	<	<2		0.23 and 0.00	Yes

5. References

[1]. BS ISO 20743:2021 Textiles – Determination of antibacterial activity of textile products.



"This report is provided on a confidential basis for the benefit of airmid healthgroup's client pursuant to the agreement between airmid healthgroup and its client. A right of action arising under this report cannot be assigned. airmid healthgroup's responsibility under this report is limited to proven negligence and will in no case be more than the testing fees. The results shown on this test report refer only to the sample(s) tested unless otherwise stated, under the conditions agreed upon. Anyone relying on this report should understand all of the details of the engagement. Only the client is authorised to publish, copy or make this report available to any third party, and then only in its entirety. This report or the airmid healthgroup limited name or logo cannot be included in any materials, including any legal, publicity or advertising activities relating to the tested product or service without the explicit written consent of airmid healthgroup Itd."

Report written by

Report	reviewed	hv
Nepon	IEVIEWEU	IJУ

Priyadarshini Senior Scientific Officer Vivienne Mahon Quality Director/Chief Scientist

*** End of Report ***